



Powered Soundbar & Speaker-Base Quick Setup Instructions:

CONNECTIONS & SETTINGS:

- For proper system setup, connect all video devices (Blu-ray/DVD, Cable/Satellite Box, Game Console, etc.) directly to the TV (not the Speaker), and connect the TV's audio output (digital or analog) to the Speaker.
- To switch between the Speaker's Digital & Analog inputs, press & hold the *Remote* Mute/Input button for 3 seconds. The Digital inputs are active when the Speaker LED is Blue; the Analog inputs are active when it is Green. If you connect the Speaker to your TV's digital output, you can then connect an audio only source (portable music player, laptop, CD player, etc.) to the Speaker's RCA inputs.
- Install batteries into the remote and connect the included power supply to the Speaker.

Connecting to your TV's Digital Audio Output:

- 1) If your TV has Optical or Coaxial digital audio outputs (usually located on the rear connection panel), use the included Optical or RCA cable (*just use one channel of the Stereo RCA cable*) to connect your TV's digital audio output to the Optical or Coaxial digital audio inputs on the rear of the Speaker.
- 2) Set your TV's digital audio output type to 'PCM' via the TV's menu (consult your TV's manual if needed).
- 3) Disable the TV's internal speakers through the TV's menu. (If you are unable to do so, simply turn the TV's volume all the way down and *only* use the Speaker remote to control the Speaker's volume.)
- 4) Using the remote, adjust the Speaker's Volume to a satisfactory level.
Using this connection type, you can control the Speaker's volume by either using the Speaker remote or by programming the Speaker to work with your TV remote (see Point #8 in the Owner's Manual).

Connecting to your TV's Headphone Output:

- 1) Use the 1/8" to Stereo RCA connection cable to connect your TV's headphone output jack (usually located on the side) to the Right & Left inputs on the rear of the Speaker.
- 2) Using the headphone jack should automatically disable the TV's internal speakers. If not, disable them via the TV's menu (see Note below).
- 3) Using this connection type, you may simply continue to use your TV remote to control the volume and do not need to use the Speaker remote.

Connecting to your TV's RCA Outputs:

- 1) Use the included Stereo RCA connection cable to connect your TV's RCA audio outputs (usually located on the rear connection panel) to the Right & Left inputs on the rear of the Speaker.
- 2) Set the TV's audio output type to 'Variable', or use Variable RCA outputs if available (consult your TV's manual). If your TV only has Fixed RCA outputs, please skip to 'Fixed RCA Outputs' section below.

Variable Outputs:

- 3) Disable the TV's internal speakers via the TV's menu (see Note below).
- 4) Using this connection type, you may simply continue to use your TV remote to control the volume and do not need to use the Speaker remote.

Fixed RCA Outputs:

- 3) Disable the TV's internal speakers through the TV's menu. (If you are unable to do so, simply turn the TV's volume all the way down and *only* use the Speaker remote to control the Speaker's volume.)
- 4) Using the remote, adjust the Speaker's Volume to a satisfactory level.
Using this connection type, you can control the Speaker's volume by either using the Speaker remote or by programming the Speaker to work with your TV remote (see Point #8 in the Owner's Manual).

Headphone / Variable RCA Connection Note: Turning the TV volume down will not work as this will result in no output on the headphone or RCA jacks for the Speaker! If you are unable to turn off your TV's internal speakers and are connected to its RCA outputs, please try using the headphone output instead.

Optional External Subwoofer:

If you would like to hook-up an external Powered Subwoofer, connect it to the Sub Out jack on the rear of the Speaker using an RCA cable. This will not affect the function of the built-in powered subwoofer in the Speaker-Base.

TO ENSURE THE BEST SYSTEM PERFORMANCE PLEASE READ THE INCLUDED OWNER'S MANUAL.