

Inwall & Ceiling Speaker Installation Instructions:

- Take the cardboard template that comes with the speakers and place it where you want the speaker to be mounted.
- Draw around the template and cutout the speaker mounting hole.
- Run quality speaker wire (12-16 gauge) to that location.
- Carefully pry off the grill from the speaker either using a small screwdriver at the edge of the grill or with a small awl catching the grill by one of its holes.
- Connect the speaker wire to the speaker terminals and insert the speaker into the hole.
- There are screws around the perimeter of the face of the speaker (6 on the inwalls, 4 on the ceiling speakers). These screws connect to 'wings' in the rear of the speaker which will swing out and clamp the speaker to the wall or ceiling as they are tightened. Secure the speaker to the wall or ceiling by tightening these screws until the speaker is securely mounted.
- Reattach grill.

That's It! Enjoy!

